

2008-10 F-250 & 350 Super Cab Rear 40-60 Bottom/Bench Top Installation

The parts of your seat cover are labeled inside. Refer to the "Seat Cover Piece Identification Chart" to identify the different parts of the seat cover.



Step 1. Top/T:

Place the seat cover on with the cut-out for the seatbelt up.



Step 2. Top:

Pull the seat cover around the left and right side, lining up the seams of the seat cover with the seams of your seat, they should closely match.



Step 3. Top:

Center the cut-out for the seatbelt and mate the hook Velcro™ sewn inside the seat cover to the carpet on the seat.



Step 4. Top:

Press the hook Velcro™ sewn inside the top of the seat cover to the carpet on the top back edge of the seat.



Step 5. Top:

Tuck the two left and right front hook Velcro™ into the seat and connect them to the corresponding loop (fuzzy) fastener sewn inside the sides of the seat cover.



Step 6. Passenger Bottom/PB:

Remove the seatbelts from their elastic restraints in the middle of the seat.



Step 7. Driver and Passenger Bottom/DB & PB:

No Carpet under seat bottoms:

Slide the seat covers on with the extending hook Velcro™ to the top and the 2" wide loop Velcro™ to the bottom. Tuck the fabric behind the latch and the plastic on the outside edges.

With the seat partway up use one hand in a smoothing action from front to back to remove slack from the seat cover, mating the hook fasteners to the loop fastener underneath.

For Carpet under the seat:

Follow same directions except press the hook Velcro™ to the carpet on the bottom of the seat.



Congratulations, you're done!

Your seat covers should fit like they're painted on, giving you several years of use, no matter how hard you use them.