1997-98 F-150 extended cab rear 40-60 Installation



Step 1. Top/T:

The parts of the seat cover are labeled inside. Use the "Seat Cover Piece Identification Chart" to identify the different parts. Flip the seat bottoms forward using the release strap behind the seatbelts,

View from under the backrest. Use a #10 Metric ratchet to remove the two bolts under the left and right side. They are located 12-16" in from the edge.



Step 2. Top/T:

Carefully lift the backrest up to remove it, taking care to avoid the sharp screws sticking out below the back window. Place the seat cover on with the long hook (sticky) Velcro™ to the top. Use one hand in a smoothing action up the front side of the seat from bottom to top, route the Velcro™ where shown though the slots in the metal, and press them to the carpeted flap on the bottom edge.



Step 3. Top/T:

Press the side hook $Velcro^{TM}$ to the carpet on the side of the seat.



Step 4. Top/T:

Lastly, connect the hook Velcro $^{\mathsf{TM}}$ along the bottom edge of the seat to the carpeted flap. This time use one hand in a smoothing action, from top to bottom.



Step 5. Driver & Passenger Bottoms/DB&PB:

Place the seat cover on with the long hook $Velcro^{\tau_M}$ to the back



Step 6. Driver & Passenger Bottoms/DB&PB:

Starting on the outside edges, feed this seat stop through the provided hole in the seat cover, then do the inside edge seat stop.



Step 7. Driver & Passenger Bottoms/DB&PB:

Press the side hook Velcro™ to the carpet on the sides of the seat. Note: The passenger inside edge has vinyl, so no Velcro™ are provided.



Step 8. Driver & Passenger Bottoms/DB&PB: Press the hook Velcro TM sewn on each side of the seatbelts to the carpet around the seatbelt cavity.



Step 9. Driver & Passenger Bottoms/DB&PB:
Flip the seat bottoms partway up and slide the hook
Velcro™ between the seat and the floor. Next, gently
pull on the Velcro™ to tighten the seat cover, and
then press it to the carpet on the front of the seat.



Step 10. Driver & Passenger Bottoms/DB&PB:
Lastly, press the hook Velcro™ sewn inside the front of the seat cover to the carpet on the seat as shown.
Note: You may have to re-position the long hook
Velcro™ to accommodate the front hook Velcro™.